

ROBSENSE

Humanise the Robotics

**EASYSWARM PERSONAL
USER MANUAL
V2.0**

ROBSENSE TECHNOLOGIES

2018

Table of Contents

1.EasySwarm	1
1.1 Overview.....	1
1.2 Open-Source	1
1.3 Hardware	1
2.EasySwarm Introduction.....	2
2.1 Networking	2
2.2 SWARM	4
2.3 SETTING	6
2.4 other	7
3.Quick Connections.....	7
3.1Hardware parameters.....	7
3.2 Flight Controller Configuration (PX4 1.7.3).....	9
4.Use Cases	10
Case 1: MAC Address Management	10
Case 2: Single drone manual control	13
Case 3: Automatically Swarming	14

1.EasySwarm

1.1 Overview

EasySwarm helps developers to fast build ultra-reliable wireless local networks for communications between a swarm of unmanned systems. Benefitted from the SwarmLink DevKit gateway, EasySwarm offers an user-friendly software to interact with customized unmanned devices, e.g. drones, AGV, UGV, etc. The EasySwarm software is free and open-source.

1.2 Open-Source

EasySwarm offers an open-source ground control software, with which developers can

- ✓ deploy customized swarming strategies
- ✓ monitor operation status of all unmanned vehicles

EasySwarm application available at RobSense website:

<http://www.robotsense.com>

EasySwarm source code available at GitHub :

<https://github.com/RobSenseTech/SwarmLink.git>

The supported open-source fly control firmware is as follows :

PX4 : V1.6.5、 V1.7.2

ArduPilot : ArduCopter V3.3.3 Quad、 ArduCopter V3.5.7 Quad

1.3 Hardware

SwarmLink Gateway


SwarmLink Node



2.EasySwarm Introduction

2.1 Networking


Select firmware version



After the software is started, the firmware selection popup window will pop up by default. Please select the flight control version of the current drone and click "Settings" .

If you have selected the firmware version, you can select "Ignore" and open the software directly. If you select "Do not display this prompt message next time", the software startup will no longer have a pop-up prompt. If necessary, you can modify it in the "System Settings" tab.


Open Serial Port



After connecting the SwarmLink gateway to the PC with the serial port tool, the software will automatically identify the serial port number of the serial device that has been connected.


After selecting the serial port number, click "Open" and the progress bar in the lower right corner will light up, prompting "Open the serial port successfully" .

Online drone list



Click the Refresh button and all nodes that have already entered the network will be displayed here. To add an access node, refer to the operations in "System Settings" -> "Gateway Whitelist Management" .


Signal quality monitoring



In the "Online drones" list, select a node and click the "Start Measurement" button to monitor the signal quality of the networking node.

2.2 SWARM

Single drone control



Select single or all online drones (ALL) to control the drone's simple operations such as unlocking, taking off, landing, and locking.

ARM: Unlock the drone.

DISARM: Lock the drone.

TAKEOFF: Let the drone that has been unlocked take off.


RTL: Return to land drone

LAND: The drone will land slowly at the current position

PAUSE: The drone will pause in the current air position until a new flight instruction is received

Operation process: ARM -> TAKEOFF -> GOTO (right map interface function) -> RTL -> DISARM.

Path planning interface



The map on the right side of the "SWARM" tab is used to perform path planning flight for a single drone. For the list of nodes on the left side, please select a single drone.

Then in the map on the right, click the right mouse button to plan several flight points in advance. Take off the drone and click on "GOTO" to fly to the set target point.

The map uses Microsoft Bing as the source. If you need to plan the flight, it is recommended to guarantee the Internet connection of EasySwarm.



SET: The height value can be set separately for each flight point. The default height value is 20 and the unit is meter. ;


GOTO: execute the currently selected point, and automatically select or manually select the next target flight point;

DEL: the currently selected flight point can be deleted;

CLER: All flight points can be cleared.

EasySwarm 2.0 supports importing drone swarm files and executing flight plans in sequence at regular intervals. The flight plan demo files are in the software root directory (SwarmPlan-3Drones.csv).

Note: Before performing a swarm flight, it is recommended to perform a single takeoff and landing test and ensure that the drone MAC in the flight plan file is consistent with the MAC in the online node list.



The base point will be used as the coordinate reference origin in the swarm flight plan file. Offset the base point, which will cause the overall offset of the swarm flight area, please fill in carefully and carefully.

Base Lon: The longitude value of the base point, please be accurate to 6 decimal places;

Base Lat: The latitude value of the base point, please be accurate to 6 decimal places;

Base Alt: The altitude value of the base point, filled in an integer value greater than or equal to 0.


IMPORT PLAN: Import flight plan files that conform to the specification. Please check the file format and the end of each line to avoid execution errors.

START: After clicking, the flight command will be executed sequentially until the execution is completed.

PAUSE: If an accident occurs during the execution, you can immediately suspend all drones and perform emergency operations such as returning and landing.

2.3 SETTING

Firmware selection




Firmware selection: Select the firmware type and version of the currently connected device.

Drone MAC modification



Drone setting: Select the connected online drone, and then fill in the new MAC address, the MAC address format is 4 digits (less than 4 digits, please add 0 to the front), click "Settings" and then power off and restart the node to complete the MAC. Address update.


Gateway whitelist management



ADD: You can add drone manually, please fill in the 4-digit MAC address number; FILE: You can import files in batches and add drones in batches. The file format is txt, and one line fills in a

DEL: Select a single MAC address, you can manually delete the drone;
CLR: Click to clear all MAC addresses, wait for the progress bar at the bottom

2.4 other



Language: Switch between Chinese and English software operating languages

Official website: Visit the official website of Robsense to get the latest firmware and software update information in time.

About: Get current software

3.Quick Connections



System settings in the function is still perfect, can only use the modified mac address

STEP 1 Connect RobSense Phenix Pro's Serial1 port with SwarmLink node UART port.

STEP 2 Connect SwarmLink Gateway micro USB with ground station.

STEP 3 Select the ground station serial number, baud rate, click open serial port.

3.1Hardware parameters

CPU : ARM Cortex-M3

Working frequency : 433MHz

Channel bandwidth : 500KHz


Modulation mode : LoRa spread spectrum

Transmit power : 20dBm

Receiving sensitivity : -148dBm

Working voltage : 5V

Working current : 50mA
Working temperature : -40°C-+85°C
Interface : CAN , MicroUSB , LAN
Size : 60mm*37mm*11mm
Weight : 20g



SwarmLink Node/Gateway : 1.TXD 2.RXD 3.VCC 4.GND

3.2 Flight Controller Configuration (PX4 1.7.3)

If the developer is using px4-1.7.3 version, there is need to modify original firmware. The red boxes below show the code to be modified or added.

Mavlink update:

```

2034
2035     if (_mode != MAVLINK_MODE_IRIDIUM) {
2036
2037         /* HEARTBEAT is constant rate stream, rate never adjusted */
2038         //     configure_stream("HEARTBEAT", 1.0f);
2039
2040         /* STATUSTEXT stream is like normal stream but gets messages from logbuffer instead of :
2041         //     configure_stream("STATUSTEXT", 20.0f);
2042
2043         /* COMMAND_LONG stream: use unlimited rate to send all commands */
2044         //     configure_stream("COMMAND_LONG");
2045
2046
2047
2048     switch (_mode) {
2049     case MAVLINK_MODE_NORMAL:
2050         configure_stream("HEARTBEAT", 1.0f);
2051         configure_stream("STATUSTEXT", 20.0f);
2052         configure_stream("COMMAND_LONG");
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063     case MAVLINK_MODE_ONBOARD:
2064         configure_stream("HEARTBEAT", 1.0f);
2065         configure_stream("STATUSTEXT", 20.0f);
2066         configure_stream("COMMAND_LONG");
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123     case MAVLINK_MODE_OSD:
2124         configure_stream("HEARTBEAT", 1.0f);
2125         configure_stream("STATUSTEXT", 20.0f);
2126         configure_stream("COMMAND_LONG");
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148     case MAVLINK_MODE_CONFIG:
2149         // Enable a number of interesting streams we want via USB
2150         configure_stream("HEARTBEAT", 1.0f);
2151         configure_stream("STATUSTEXT", 20.0f);
2152         configure_stream("COMMAND_LONG");
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675
2676
2677
2678
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916
2917
2918
2919
2920
2921
2922
2923
2924
2925
2926
2927
2928
2929
2930
2931
2932
2933
2934
2935
2936
2937
2938
2939
2940
2941
2942
2943
2944
2945
2946
2947
2948
2949
2950
2951
2952
2953
2954
2955
2956
2957
2958
2959
2960
2961
2962
2963
2964
2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2999
3000

```

1. Find the firmware/SRC/module/mavlink/mavlink_main.cpp file.
2. Add code in the corresponding position, as shown in the 1, 2, 3, 4 and 5 steps shown above.

Turn off serial port flow control:

```

564 float      _rate_tx;
565 float      _rate_txerr;
566 float      _rate_rx;
567
568 int        _swarm_link_uart_fd; 1
569
570 _rate_txerr(0.0f),
571 _rate_rx(0.0f),
572 _swarm_link_uart_fd(-1), 2
573 #ifdef __PX4_POSIX
574 mvdadr {l
575
576 _uart_fd = ::open(uart_name, O_RDWR | O_NOCTTY);
577
578 if(!(strcmp(uart_name, "/dev/ttyS1"))) 3
579 {
580     _swarm_link_uart_fd = _uart_fd;
581 }
582
583 if(_swarm_link_uart_fd == _uart_fd) 4
584 {
585     uart_config.c_cflag &= ~CRTSCTS;
586 }
587
588 ret = tcsetattr(_uart_fd, TCSANOW, &uart_config);
589
590

```

1. Find the firmware/SRC/module/mavlink/mavlink_main.h file.
2. Add code in the corresponding position, as shown in the 1 steps shown above.
3. Find the firmware/SRC/module/mavlink/mavlink_main.cpp file.
4. Add code in the corresponding position, as shown in the 2,3,4 steps shown above.

Modify boot file:

```

578
579 if [ "$MAVLINK_F" == xnone ]
580 then
581 else
582     echo "mavlink MAVLINK_F = ${MAVLINK_F} start"
583     mavlink start ${MAVLINK_F} -m magic -r 1000 -f
584 fi
585 unset MAVLINK_F
586

```

1. find firmware/ROMFS/px4fmu_common/init.d/rcS file.
2. add the code at the corresponding location, as shown in the red area above.

4. Use Cases

Case 1: MAC Address Management

The default MAC address of SwarmLink is FDFD0001, which can be customized changed for the purpose of networking.


Hardware : SwarmLink Gateway、SwarmLink Node、PC.

Software : EasySwarm2.0.

Note: You can only modify one node at a time, multiple nodes, please modify them separately.



Modify the MAC address :

1. Open the gateway serial port




1. Click on the "NETWORK" tab
2. Select the serial port number of the gateway connection
3. Click "Open" and "Success" is displayed in the lower right corner, indicating that the gateway has successfully accessed. At this point, the factory node can also be powered on.
4. Click to refresh the list on the left. If the 0001 node appears, skip step 2.

2. Add 0001 node to the gateway (you can skip this step if you have added)



1. Switch to the "SETTING" tab
2. Click on "Gateway"
3. Enter the node MAC address: 0001,
4. Click "ADD". If you see the 0001 node in the white list below, the addition is successful. At this point, the factory node needs to be powered off and restarted.
5. Click on the "NETWORK" tab
6. Click Refresh to see if online node 0001 appears. If successful, go to step 3.

3. Modify the drone MAC address



1. Click on the "SETTING" tab
2. Click on "Drone"
3. Pull down and select the "0001" node
4. Fill in the new 4-digit MAC address
5. Click on "SET" and the prompt "Success" will pop up. Power off and restart the factory node, then refresh the online node list to view the modification.


Note: If the new MAC address is not in the gateway whitelist, repeat the Add Gateway Whitelist operation in step 2 and refresh again.

Case 2: Single drone manual control

Hardware : Phenix Pro DevKit , RobSense RST330 research drone、 SwarmLink gateway、 SwarmLink node、 PC

Software : EasySwarm2.0

Note: Before the drone is controlled by a single unit, you need to perform networking operations. Repeat steps 1 and 2 in Case 1 to complete the node addition. Once the drone node appears in the online list, you can proceed.




1. Switch to the "SWARM" tab
2. Click the refresh button
3. The drone node appears in the list, left click to select
4. In the map on the right, drag the map area with the left button, zoom in and out on the map, and right click on the map to plan the flight point. When finished, click the flight point No. 1.
5. Place the drone near the flight point No. 1, click "ARM", wait for the drone to unlock
6. Set the takeoff height (m), click "TAKEOFF", wait for the drone to take off to the specified height
7. Click on "GOTO" and the drone will fly to the currently selected flight point.
8. After completing the flight, click on "RTL" and the drone will return to the takeoff location and land automatically.

Case 3: Automatically Swarming

Hardware : RobSense RST330 research drone , RobSense Phenix Pro DevKit , SwarmLink Gateway,SwarmLink Node,PC (windows) .

Software : EasySwarm2.0

Note: Before swarm flight, you need to perform swarmLink networking and single-machine manual take-off and landing control test. For details, see Case 1 and Case 2.



1. Fill in the longitude, latitude, and altitude of the base point. The longitude and latitude need to be accurate to 6 digits after the decimal point, and the height is an integer greater than or equal to 0.
2. Import flight plan file, the format is csv, can be opened with excel, there is "SwarmPlan-3Drones.csv" under the software root directory, which can be used as a test file to directly import flight. You can also write your own flight files according to the flight plan file format specification.
3. Separate the drones on the ground, pay attention to the order of the drones (for example, the order of the demo files is from north to south, in the order of 1, 2, 3), click the "START" button. The drone will automatically execute the flight plan file at set intervals.
4. In the process of swarm flight, if there is an accident, please click the "PAUSE" button of the formation function for the first time, then return or land according to the actual situation, and do not support direct return.

Note: The drone's ARM, TAKEOFF, GOTO, RTL and other operations can be completed in the flight plan file.

Flight plan file preparation instructions:

The following are flight file format specifications:

A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q
序号	提示	指令	间隔(秒)	节点MAC地址(无须加0补齐4位)	向东(米)	向北(米)	高度(米)	节点MAC地址	向东(米)	向北(米)	高度(米)	节点MAC地址	向东(米)	向北(米)	高度(米)	结果符
1	解锁	ARM	0.5		1	0	0	0	2	0	0	0	3	0	0	0 ENDL
2	起飞	TAKEOFF	20		1	0	0	25	2	0	0	25	3	0	0	25 ENDL
3	1-3 GOTO 调整位置	GOTO	20		1	0	0	25	2	0	-5	25	3	0	-10	25 ENDL
4	1-3 东飞行 20米	GOTO	20		1	20	0	25	2	20	-5	25	3	20	-10	25 ENDL
5	2-3 东北飞行	GOTO	20		2	25	0	25	3	30	0	25	ENDL			
6	1-3 北飞行 20米	GOTO	20		1	20	20	25	2	25	20	25	3	30	20	25 ENDL
7	1-3 西北飞行	GOTO	20		2	20	25	25	3	20	30	25	ENDL			
8	1-3 西飞行 20米	GOTO	20		1	0	20	25	2	0	25	25	3	0	30	25 ENDL
9	1-3 西南飞行 20米	GOTO	20		2	-5	20	25	3	-10	20	25	ENDL			
10	1-3 南飞行 20米	GOTO	20		1	0	0	25	2	-5	0	25	3	-10	0	25 ENDL
11	1-3 东南飞行 20米	GOTO	20		2	0	-5	25	3	0	-10	25	ENDL			
12	3-1 返航	RTL	0		3	0	0	0	2	0	0	0	1	0	0	0 ENDL

Column A - Serial number: starting from 1 and filling in ascending order

Column B - Tip: Plain text content, only used to prompt the instruction of the line, improve readability

Column C - Instruction: Includes ARM, TAKEOFF, GOTO, RTL. Only one flight instruction is allowed in a row.

Column D - Interval (seconds): After the execution of the command is completed, wait for N seconds and execute the next line. If the flight distance is long, it is recommended to increase the time interval.

Column E - Node MAC address (no need to add 0 to fill 4 digits): Fill in the MAC address of the drone node that needs to be in formation flight.

Column F- east (meter): If it is a GOTO command, it represents the offset of the flight point relative to the base point, with a positive integer to the east and a negative integer to the west.

Column G - north(meter):: If it is a GOTO command, it represents the north-south offset of the flight point relative to the base point, with a positive integer to the north and a negative integer to the south.

Column H-height (meter): If it is a TAKEOFF command, it represents the takeoff altitude of the drone; if it is a GOTO command, it represents the up and down offset of the flight point relative to the base point, up to a positive integer, down to Negative integer.

Column Q- terminator: Each line must be filled with an ENDL at the end, indicating the end of the line instruction.

ROBSENSE

Humanise the Robotics

Hangzhou Robsense Technology Co., Ltd.

Cell : +86-18510261028

E-Mail : sales@robsense.com

National High-level Oversea Talent Innovation Base

Binjiang, Hangzhou City, China